## Demo 5 Exercises: Play a Wave file

DSP Lab (ECE 4163 / ECE 6183)

2019

Demo files:

```
play_wave_mono.py
play_wave_stereo.py
demo_sys.py
```

The demo python program play\_wave\_mono.py shows how to read and play a wave file using PyAudio. It is assumed the wave file is mono (single channel). The program play\_wave\_stereo plays a stereo (two channel) wave file.

In this demo, we use a while loop to write signal values to the audio output. Inside the loop, we use unpack() and pack() to convert between binary strings and lists of integers. In the while loop, we use the variable gain to amplify the signal and the function clip16() to keep the value within the range of a signed 16-bit integer to avoid potential overflow run-time errors. Correspondingly the format string h (hh for stereo) is used in the unpack() and pack() methods to set the encoding format.

Documentation for the wave module is at

https://docs.python.org/3/library/wave.html

## **Exercises**

1. **Single program for mono and stereo.** Write a single Python program to play both mono SUBMIT and stereo wave files. The program should determine the number of channels by reading the wave file information.

Verify that your program can play both mono and stereo wave files encoded with 16-bits per sample.

- 2. Modify your previous program so it can be used at the command line like
  - >> python my\_play\_wave.py filename.wav

You will need to import the sys module.

For example, consider the Python demo program demo\_sys.py

```
1  # demo_sys.py
2
3  import sys
4
5  for i in range(len(sys.argv)):
    print('Argument %d is %s ' % ( i, sys.argv[i] ) )
```

We run this at the terminal command line:

```
>> python demo_sys.py abc.wav 10 h20
Argument 0 is demo_sys.py
Argument 1 is abc.wav
Argument 2 is 10
Argument 3 is h20
```